



GPS 4G WATCH

| Quick start guide

FOR EASY SET UP, FOLLOW THE CHECK LIST:

- Check what is in the box
- Fully charge your device
- Turn on your device
- Share your device number with your programmed contacts

This device comes fully programmed, including with an active Sim card on the Telstra network for your convenience.

This device is configured for falls detection: Yes No

WHAT'S IN THE BOX



Watch



USB charging cable



Power adapter



Charging base



Manufacture's quick start guide

* for reference only



For FIRST TIME USE, please fully charge the battery for around 2 or 3 hours.

When the battery level falls below 20%, the device will send you a low battery warning message. Your contacts will also receive it via text message.

How to TURN ON THE WATCH

STEP 1

Plug the USB charging cable into the power adapter and connect to the charging base.

STEP 2

Plug the power adapter base into a power outlet and sit watch in it's charging base.

STEP 3

The device will turn on after approximately 10 minutes. Alternatively you can press and hold the side button for 2 seconds to turn it on.

STEP 4

The watch will chime as it turns on.

STEP 5

A welcome message will appear on the watch face.

DO YOU NEED HELP? Send an ALERT!

- 1 Locate the **(SOS) button** on the side of the watch
- 2 **Press and hold** the SOS button for 4 seconds to activate an alert.
- 3 The watch will:
 - **If 24/7 response centre monitored**, call the response team
 - **If back to programmed contacts**, send an SMS notification for assistance with a google map link to your location

Your device is programmed for:

- 24/7 response centre**
 Programmed contacts

Programmed contacts

1. _____
2. _____
3. _____
4. _____
5. _____
6. _____
7. _____
8. _____
9. _____
10. _____

THIS IS YOUR DEVICE PHONE NUMBER:

Please share the above number with your programmed contacts, so they can call your device and check on you.

If you or your programmed contacts need specific information, you can send the following text messages to your device's phone number:

loc To query your location

battery To check the battery percentage

findme To find your device within the home. To cancel the call after you found your device, press the SOS button quickly

The response will be sent immediately if your device is on.


*Please consult the included manufacturer's quick start guide for additional information on the pendant's features.

Contacts for further support, emergency or servicing:


**24/7 Response
Monitoring Connection**

Press **'EMERGENCY CALL'**
button on device

**Emergency
Services**

 **000** or press
'EMERGENCY CALL'
button on device

**Technical
Support only**

 **1300 851 771**
Monday to Friday,
6am to 8pm.

